

Kodak 805 Photo Printer

Printer Driver Guide



Contents

Printer Driver Guide

Overview

- About the Printer Driver
- Features of the Printer Driver
- About the Online Guide
- Getting Help or Additional Information

Installing the Driver

- Hardware and Software Requirements
- Installing the Driver
- Uninstalling the Driver
 - WINDOWS VISTA Operating System
 - WINDOWS XP Operating System
 - WINDOWS 2000 Operating System

Using the Driver with the WINDOWS VISTA / XP / SERVER 2003 Operating System

- Changing Print Options from an Application
 - Options on the Layout Tab
 - Options on the Paper/Quality Tab
 - Options on the Adjust Color Tab
 - Options on the About Tab

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Advanced Options

Changing Print Options from the Operating System

Options on the Color Management Tab

Options on the Printer Calibration Tab

Using the Driver with the WINDOWS 2000 Operating System

Changing Print Options from an Application

Options on the Paper Tab

Options on the Color Adjustment Tab

Changing Print Options from the Operating System

Search

Help

Navigating

Printing

Magnifying

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Overview

Welcome to the online guide for the KODAK 805 Photo Printer Driver for WINDOWS Operating Systems. The printer driver provides access to the printer features.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

CONTENTS

SEARCH

HELP

About the Printer Driver

The printer driver allows the software applications you use to access the printer features. For example, your application determines the page breaks, font selection, and page setup for your print job. The printer driver translates this information into a printer language and sends the job to the printer. The printer driver's graphical user interface gives you access to additional printing options that are not available from your software application.

Access the features for the printer driver from the print and page setup commands in the application you are using.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Features of the Printer Driver

Overview

The printer driver provides the following printing options that are not available directly from your software application:

Color Management

Choose how to manage the color in your prints. You can make prints using the default color settings, then adjust the color, brightness, contrast, and saturation.

Calibration

Calibrate the printer by making a test print and selecting the most neutral color patch.

Layout

Choose layout options such as orientation, page order, number of copies, mirroring, sharpening, and scaling.

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

About the Online Guide

Overview

This guide includes the following sections:

- Installing the Driver—provides instructions on how to install and remove the printer driver on your computer
- Using the Driver—describes how to use the printer driver with the printer

Click **HELP** at the bottom of the screen for more information on using and printing this guide, or click the tabs at the right to learn more about using the printer driver.

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

CONTENTS

SEARCH

HELP

Getting Help or Additional Information

Your dealer of Kodak products is the best source for information about setting up, operating, and obtaining accessories and supplies for your printer. Contact your dealer with any questions.

For more information, refer to “Troubleshooting” in the *KODAK 805 Photo Printer User’s Guide*.

Go to www.kodak.com and select **All KODAK Businesses > Pro Photographer / Lab:**

- for service
- for help setting up or operating the printer
- to download printer drivers
- to obtain supplies
- for warranty information
- for information about other Kodak products

For technical support in the US, call 1-800-23KODAK (1-800-235-6325) between 9:00 a.m. and 8:00 p.m. Eastern Standard Time on regular business days.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Installing the Driver

The printer driver is a KODAK Driver customized for use with the 805 Photo Printer. The following installation instructions assume that you are familiar with MICROSOFT WINDOWS Operating Systems and terminology.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

CONTENTS

SEARCH

HELP

Hardware and Software Requirements

We recommend that you have the following minimum hardware and software to use the printer driver:

- WINDOWS VISTA, WINDOWS XP, WINDOWS SERVER 2003, or WINDOWS 2000 Operating System (32-bit or 64-bit versions)
- 512 MB RAM minimum for WINDOWS VISTA Operating System; 256 MB RAM minimum for WINDOWS XP, WINDOWS SERVER 2003, or WINDOWS 2000 Operating System
- PENTIUM III Processor
- Color monitor with a minimum pixel resolution of 800 x 600
- Available USB port (USB 2.0 preferred)

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Installing the Driver

1. Go to www.kodak.com.
2. Select **All KODAK Businesses > Pro Photographer / Lab**.
3. Navigate to the Support Center.
4. Download the printer driver.
5. Follow the instructions to install the printer driver.
6. Connect the printer to the computer.
7. Press the POWER switch to turn on the printer.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Uninstalling the Driver

WINDOWS VISTA Operating System

1. Select **Start > Control Panel > Hardware and Sound > Printer**.
The Printers dialog box appears.
2. Right-click the printer you want to remove, and select **Delete**.
3. Right-click the dialog box, and select **Run as administrator > Server Properties**.
4. If the User Account Control dialog box appears, click **Continue**.
5. To remove the printer driver software:
 - a. Select **Drivers**.
 - b. Select the printer driver you want to remove, and click **Remove**.
 - c. Select **Remove driver and driver package**.
 - d. Click **OK**.
 - e. Click **Yes**.
 - f. Click **Delete**.
 - g. Click **OK**.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

WINDOWS XP Operating System

1. Select **Start > Printers and Faxes**.

The Printers and Faxes dialog box appears.

2. Right-click the printer you want to remove, and select **Delete**.
3. Click **Yes**.
4. To remove the printer driver software:
 - a. Select **File > Server Properties**.
 - b. Select **Drivers**.
 - c. Select the printer driver you want to remove, and click **Remove**.
 - d. Click **Yes**.
 - e. Click **Close**.

WINDOWS 2000 Operating System

1. Select **Start > Settings > Printers**.
2. Right-click the printer you want to remove, and select **Delete**.
3. Click **Yes**.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Using the Driver with the WINDOWS VISTA / XP / SERVER 2003 Operating System

This section describes how to use the printer driver to send print jobs to the KODAK 805 Photo Printer from your computer.

NOTE: This section shows dialog boxes for the WINDOWS XP Operating System. The dialog boxes for the WINDOWS VISTA and WINDOWS SERVER 2003 Operating Systems look similar and have identical functionality.

Overview

Installing the Driver


Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Changing Print Options from an Application

You can use the Printing Preferences dialog box to select print options from an application.

1. In your application, select **Print** from the File menu.
2. Depending on the application, click **Properties** or **Setup** in the Print dialog box.
3. Select options from the tabs in the Printing Preferences dialog box (shown on the following pages), then click:
OK—to save your selections and close the dialog box
Cancel—to cancel your selections and close the dialog box
Apply—to save your selections without closing the dialog box
4. Depending on the application, click **OK** or **Print** in the Print dialog box.



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the Layout Tab

You can select the following options on the Layout tab:

Orientation

Portrait—orients the print vertically

Landscape—orients the print horizontally


Page Order

Front to Back—prints the pages in order from front to back

Back to Front—prints the pages in order from back to front

Pages Per Sheet—sets the number of pages to print on each sheet

Advanced—displays the Advanced Options dialog box (see [Advanced Options](#))



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System


Options on the Paper/Quality Tab

You can select the following options on the Paper/Quality tab:

Paper Source—does not affect the output of the printer

Advanced—displays the Advanced Options dialog box (see [Advanced Options](#))

NOTE: Refer to “Working with Paper” in the *KODAK 805 Photo Printer User’s Guide* for a complete listing of paper, ribbon, and image sizes.



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the Adjust Color Tab

You can select the following options on the Adjust Color tab:

Brightness—adjusts the relative lightness or darkness

Contrast—adjusts the relationship between the light areas, midtones, and dark areas


Saturation—adjusts the intensity of the colors

Gamma—adjusts the lightness or darkness of the midtones

Red—adds or subtracts red

Green—adds or subtracts green

Blue—adds or subtracts blue



Overview


Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the About Tab

You can view the driver version on the About tab.



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Advanced Options

If you select the **Advanced** button on the Layout tab or the Paper/Quality tab, the Advanced Options dialog box appears.

You can select the following options in the Advanced Options dialog box:

Paper/Output

Paper Size—sets the paper size (8.5 x 12 in. or 8.5 x 14 in.) for the print job

Copy Count—sets the number of prints

Document Options


Mirrored Output—reverses the print, producing a mirror image

Rotate 180—rotates the print 180°

XtraLife—(recommended) adds a protective overcoat to the print

Sharpen—sets an amount of None, Normal, or High image enhancement to improve the sharpness of the print

Scaling—scales a print by a specified percentage



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Changing Print Options from the Operating System

You can use the Printer Properties dialog box to select print options from the operating system.

1. Navigate to the Printers folder.
2. Right-click the driver for the printer, and select **Properties**.
3. Select options from the tabs in the Printer Properties dialog box (shown on the following pages), then click:

OK—to save your selections and close the dialog box

Cancel—to cancel your selections and close the dialog box

Apply—to save your selections without closing the dialog box

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the Color Management Tab

You can select color profiles on the Color Management tab.


Automatic—computer selects the color profiles automatically

Manual—lets you select the color profiles manually

Add—adds the color profiles

Remove—removes the selected color profile

Set As Default—lets you select the default profile manually (Manual mode only)



Overview

Installing the Driver


Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the Printer Calibration Tab

You can launch the KODAK Photo Printer Visual Calibration Utility on the Printer Calibration tab.

NOTE: You can also launch the utility from the Start menu, as shown in the *KODAK 805 Photo Printer User's Guide*. Refer to "Calibrating the Printer" in the User's Guide for instructions on using the Utility.



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Using the Driver with the WINDOWS 2000 Operating System

This section describes how to use the printer driver to send print jobs to the KODAK 805 Photo Printer from your computer.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

CONTENTS


SEARCH

HELP

Changing Print Options from an Application

You can use the Printing Preferences dialog box to select print options from an application.

1. In your application, select **Print** from the File menu.
2. Depending on the application, click **Properties** or **Setup** in the Print dialog box.
3. Select options from the tabs in the Printing Preferences dialog box (shown on the following pages), then click:
OK—to save your selections and close the dialog box
Cancel—to cancel your selections and close the dialog box
Apply—to save your selections without closing the dialog box
4. Depending on the application, click **OK** or **Print** in the Print dialog box.



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the Paper Tab

You can select the following options on the Paper tab:

Paper Size—selects the paper size (8.5 x 12 in. or 8.5 x 14 in.) for the print job

XtraLife—(recommended) adds a protective overcoat to the print

NOTE: Refer to “Working with Paper” in the *KODAK 805 Photo Printer User's Guide* for a complete listing of paper, ribbon, and image sizes.


Orientation

Portrait—orients the print vertically

Landscape—orients the print horizontally

Rotate 180—rotates the print 180°

Mirror—reverses the print, producing a mirror image



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Option

Copies—sets the number of prints

Scaling—scales a print by a specified percentage

Sharpness—sets an amount of None, Normal, or High image enhancement to improve the sharpness of the print

Defaults—restores the driver default settings

About—lists the software version of the printer driver

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Options on the Color Adjustment Tab

You can select the following options on the Color Adjustment tab:

Brightness—adjusts the relative lightness or darkness

Contrast—adjusts the relationship between the light areas, midtones, and dark areas

Gamma—adjusts the lightness or darkness of the midtones

Red—adds or subtracts red


Green—adds or subtracts green

Blue—adds or subtracts blue

Reset—resets all the settings to 0

Load—opens a dialog box that lets you locate a document containing saved settings that can be applied to the current print

Save—opens a dialog box that lets you save the settings to a file



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Changing Print Options from the Operating System

You can use the Printer Properties dialog box to select color profiles from the operating system.

1. Navigate to the Printers folder.
2. Right-click the driver for the printer, and select **Properties**.
3. Click the **Color Management** tab.
4. Select from the following options:


Automatic—computer selects the color profiles automatically

Manual—lets you select the color profiles manually

Add—adds the color profiles

Remove—removes the selected color profile

Set As Default—lets you select the default profile manually (Manual mode only)



Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

5. Click:

OK—to save your selections and close the dialog box

Cancel—to cancel your selections and close the dialog box

Apply—to save your selections without closing the dialog box

Overview

Installing the Driver


Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Search

You can search this guide for desired information. This function is executed through the search utilities of ADOBE ACROBAT.

To search within this guide:

1. Click the find tool  in the toolbar to open the Find dialog box.
2. Enter the word or phrase you want to find.
3. Click **Find** to begin the search.

The first occurrence of the word or phrase is highlighted.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Help

Refer to the following procedures for help navigating, printing, and magnifying this guide.

Navigating

Use the links within the windows and the standard tools of ADOBE ACROBAT to navigate the guide. For more information about the tools, see the documentation for ADOBE ACROBAT.

Identifying the Active Section

The tabs on the right side of your window identify the sections. The active section is shown as a white tab with a yellow arrow.

Opening Sections

To open a different section, click the desired tab.

Following a Link

Cross-referenced information is identified with blue text. To view the referenced information, click the blue text.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Browsing

You can also browse through the guide using the browse buttons in the toolbar at the top or bottom of the window.



Displays the next page



Displays the previous page



Displays the first page of the guide



Displays the last page of the guide

Printing

To print, select **Print** from the File menu. Complete the dialog box and send the print request.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System

Magnifying

Some of the images are better viewed at a larger magnification. To change the view magnification, use the controls in the toolbar, or click and drag in the page with the zoom tool.

Use of the Toolbar View Buttons

Click one of the three page view buttons on the toolbar to change the magnification of the page.



Actual size




Fits in window




Fits width of window

Using the Zoom Buttons

You can use the zoom buttons to zoom in or zoom out of an area on the page.

To magnify an area, click the zoom in tool  and draw a rectangle around an area on the page.

To reduce the magnification of an area, click the zoom out tool  and click the area of the page to zoom out.

Overview

Installing the Driver

Using the Driver -
WINDOWS VISTA /
XP / SERVER 2003
Operating System

Using the Driver -
WINDOWS 2000
Operating System



Eastman Kodak Company
343 State Street
Rochester, NY 14650 U.S.A.

© Kodak, 2008.
TM: Kodak, XtraLife. All rights reserved.
P/N 4J6569